


Position of Parts in Body























H 1 Front No. 1 Speaker Assembly RH
H 3 Front Door Courtesy Light Assembly RH
H 4 Front Power Window Regulator Motor Assembly RH
H 6 Door Control Switch Assembly
H 7 Front Door with Motor Lock Assembly RH
H 8 Front Power Window Regulator Switch Assembly RH
H 10 Door Side Airbag Sensor RH
H 11 Outer Rear View Mirror Assembly RH
H 12 Outer Mirror Control ECU Assembly RH
H 13 Outer Mirror Control ECU Assembly RH

I 1 Front No. 1 Speaker Assembly LH
I 3 Front Door Courtesy Light Assembly LH
I 4 Front Power Window Regulator Motor Assembly LH
I 6 Power Window Regulator Master Switch Assembly
I 7 Front Door with Motor Lock Assembly LH
I 9 Door Side Airbag Sensor LH
I 10 Seat Memory Switch
I 11 Outer Rear View Mirror Assembly LH
I 12 Outer Mirror Control ECU Assembly LH
I 13 Outer Mirror Control ECU Assembly LH

J 1 Rear Power Window Regulator Switch Assembly RH
J 2 Rear Power Window Regulator Switch Assembly RH
J 3 Rear Door with Motor Lock Assembly RH
J 4 Rear Speaker Assembly RH
J 5 Rear No. 2 Speaker Assembly RH

K 1 Rear Power Window Regulator Switch Assembly LH
K 2 Rear Power Window Regulator Motor Assembly LH
K 3 Rear Door with Motor Lock Assembly LH
K 4 Rear Speaker Assembly LH
K 5 Rear No. 2 Speaker Assembly LH

Position of Parts in Body



Position of Parts in Body

