


Position of Parts in Body <LHD>

- * 1:w/ Curtain Shield Airbag
- * 2:w/o Curtain Shield Airbag
- * 7:Before Jul. 2010 Production
- * 8:From Jul. 2010 Production
- * 9:Before Nov. 2012 Production
- * 10:From Nov. 2012 Production



- N 1 Front Door Courtesy Light Switch Assembly LH
- N 2 Front Pretensioner LH
- N 3 Rear Door Courtesy Light Switch Assembly LH
- N 5 Rear Combination Light Assembly RH
- N 6 Rear Combination Light Assembly LH
- N 7 Front Seat Inner Belt Assembly LH
- N 8 Front Side Airbag Sensor Assembly LH
- N 9 Front Side Airbag Sensor Assembly LH
- N 10 Rear Side Airbag Sensor Assembly LH
- N 11 Curtain Shield Airbag Assembly LH
- N 12 Rear Seat Inner Belt Assembly LH
- N 13 Rear Seat Inner Belt Assembly Center
- N 14 Rear Power Point Socket Assembly
- N 15 Front Side Airbag Squib Circuit LH
- N 16 Front Seat Heater Assembly LH
- N 18 Fuel Sender Gage Assembly
- N 19 No. 2 Room Light Assembly
- N 20 Noise Filter (Rear Window Defogger)
- N 21 Rear Indoor Electrical Key Oscillator
- N 22 Outside Luggage Electrical Key Antenna
- N 24 Rear No. 2 Seat Belt Sub Assembly Inner
- N 25 Diode (Back Door Courtesy Switch)
- N 26 Junction Connector
- N 27 Front Side Airbag Sensor Assembly LH
- N 28 Front Side Airbag Sensor Assembly LH
- N 29 Rear Side Airbag Sensor Assembly LH
- N 30 Front Door Courtesy Light Switch Assembly LH
- N 31 Rear Door Courtesy Light Switch Assembly LH
- N 32 Tire Pressure Warning ECU and Receiver (Tire Pressure Monitor Receiver Assembly)

Position of Parts in Body <LHD>

