



- * 1:w/ VSC
- * 2:w/o VSC
- * 3:Hong Kong
- * 4:Except Hong Kong
- * 5:w/o Automatic Light Control Hong Kong
- * 6:w/o Automatic Light Control Except Hong Kong
- * 7:w/ Entry & Start System
- * 8:w/o Entry & Start System




- F 1 Combination Meter Assembly
- F 2 Hazard Warning Signal Switch Assembly
- F 3 Combination Meter Assembly
- F 4 DLC3
- F 5 Spiral Cable Sub-Assembly
- F 6 Power Steering ECU Assembly
- F 7 Outer Mirror Switch Assembly
- F 8 Headlight Leveling Switch
- F 9 Headlight Dimmer Switch Assembly
- F 10 Headlight Dimmer Switch Assembly
- F 11 Windshield Wiper Switch Assembly
- F 12 Windshield Wiper Switch Assembly
- F 13 Ignition or Starter Switch Assembly
- F 14 Key Inter Lock Solenoid
- F 15 Un-Lock Warning Switch Assembly
- F 16 Center Airbag Sensor Assembly
- F 17 Spiral Cable Sub-Assembly
- F 19 Lower No. 1 Instrument Panel Airbag Assembly
- F 20 Airbag Cut Off Switch Cylinder Sub-Assembly
- F 21 Telltale Light Assembly
- F 22 Parking Brake Switch Assembly
- F 23 Shift Lock Control ECU Sub-Assembly
- F 24 Shift Lock Control ECU Sub-Assembly
- F 25 Transmission Control Switch
- F 26 Shift Position Indicator (Floor Shift Position Indicator Housing Sub-Assembly)
- F 27 Power Outlet Socket Assembly
- F 28 Pattern Select Switch Assembly
- F 30 Steering Sensor

Position of Parts in Instrument Panel <RHD>


F 1
Black




F 2
Gray




F 3
White




F 4
White




F 5
Black




F 6
Black




F 7
White




F 8
Black




F 9
Black




F 10
White




F 11
White



F 12
White



F 13
White




F 14
Black




F 15
White




F 16
Yellow



F 17
Yellow



F 19
Black



Position of Parts in Instrument Panel <RHD>

