

K30
K27
K9
K42
K2
K28
K43
K1
K29
K8
K44
K38
K46
K26
K25
K45
K39
K12
K37
K17

K 1 Front Door Courtesy Light Switch Assembly LH
K 2 Front Door Courtesy Light Switch Assembly RH
K 8 Front Seat Inner Belt Assembly LH
K 9 Front Seat Inner Belt Assembly RH
K 12 Door Control Receiver
K 17 Fuel Sender Gage Assembly
K 25 Front Seat Outer Belt Assembly LH
K 26 Front Seat Outer Belt Assembly RH
K 27 Curtain Shield Airbag Assembly LH
K 28 Curtain Shield Airbag Assembly RH
K 29 Front Seat Airbag Assembly LH
K 30 Front Seat Airbag Assembly RH
K 37 Rear Combination Light Assembly LH
K 38 Rear Combination Light Assembly RH
K 39 No. 2 Room Light Assembly
K 42 Noise Filter (Rear Window Defogger)
K 43 Rear Speaker Assembly LH
K 44 Rear Speaker Assembly RH
K 45 No. 2 Side Airbag Sensor Assembly LH
K 46 No. 2 Side Airbag Sensor Assembly RH


K 1
White




K 2
White




K 8
White



K 9
White




K 12
White




K 17
White




K 25
Black




K 26
Black




K 27
Black




K 28
Black




K 29
Yellow




K 30
Yellow




K 37
Gray




K 38
Gray




K 39
White




K 42
Black




K 43
White



K 44
White



K 45
Yellow



K 46
Yellow

