

Remote Control Mirror
1
2
3
4
(ACC)
5A
ACC
13
3B
GR
D105
Outer Mirror Switch Assembly
8
B
Left
Right
Up
Down
Left/
Up
Right/
Down
Operation
Switch
Select
Switch
HL
HR
VL
VR
M+
E
5
2
4
3
6
7
V
L
R
B
W
W–B
8
B
9
B
3
A
D148(A), D149(B)
Junction
Connector
W
L
P
10
GD3
19
GD3
9
GD3
19
FD3
10
FD3
9
FD3
BE
B
P
B
SB
P
3
5
4
MH
MV
M+
M
G24
Outer Rear View Mirror
Assembly LH
F24
Outer Rear View Mirror
Assembly RH
5
8A
D1