
F RELAY LOCATIONS

[Body]

(5-Door)


* 1:w/o Tire Pressure Warning System
* 2:w/ Tire Pressure Warning System



Door Control Receiver (*1)
Tire Pressure Warning ECU and Receiver
(Door Control and Tire Pressure Monitoring System
Receiver Assembly) (*2)

(3-Door)

* 1:w/o Tire Pressure Warning System
* 2:w/ Tire Pressure Warning System



Door Control Receiver (*1)
Tire Pressure Warning ECU and Receiver
(Door Control and Tire Pressure Monitoring System
Receiver Assembly) (*2)