


* 1:w/o Tire Pressure Warning System
* 2:w/ Tire Pressure Warning System

J 60 Front Door Courtesy Light Switch Assembly LH
J 61 Front Door Courtesy Light Switch Assembly RH
J 64 Rear Combination Light Assembly LH
J 65 Rear Combination Light Assembly RH
J 66 No. 2 Room Light Assembly
J 68 Door Control Receiver
J 69 Tire Pressure Warning ECU and Receiver (Door Control and Tire Pressure Monitoring System Receiver Assembly)
J 70 Canister Pump Module
J 71 Fuel Sender Gage Assembly
J 72 Noise Filter (Rear Window Defogger)
J 73 Side Airbag Sensor Assembly LH
J 74 Side Airbag Sensor Assembly RH
J 75 No. 2 Side Airbag Sensor Assembly LH
J 76 No. 2 Side Airbag Sensor Assembly RH
J 77 Front Seat Outer Belt Assembly LH
J 78 Front Seat Outer Belt Assembly RH
J 79 Curtain Shield Airbag Assembly LH
J 80 Curtain Shield Airbag Assembly RH
J 90 Rear Speaker Assembly LH
J 91 Rear Speaker Assembly RH

J 60
White



J 61
White



J 64
Gray




J 65
Gray



J 66
White




J 68
White



J 69
White




J 70
Black




J 71
White




J 72
Black




J 73
Yellow




J 74
Yellow




J 75
Yellow




J 76
Yellow




J 77
Black




J 78
Black



J 79
Black



J 80
Black



J 90
White



J 91
White

