

Wiring diagram for the L12 Pre-Crash Safety City Sensor. The diagram shows the electrical connections between the sensor unit and various vehicle components.


Legend:

- * 3 : w/ Lane Departure Alert
- * 4 : w/ Pre-Crash Safety System
- * 5 : 1NR-FE
- * 8 : Before Oct. 2016 Production
- * 9 : From Oct. 2016 Production
- * 10 : Before Mar. 2017 Production
- * 11 : From Mar. 2017 Production
- * 12 : From Oct. 2016 Production until Mar. 2017 Production
- * 13 : IND-TV
- * 14 : 1KR-FE
- * 15 : Before May 2018 Production
- * 16 : From May 2018 Production
- * 17 : From Mar. 2017 Production until May 2018 Production

- | | |
|-----------------------------------|----------------------------------|
| * 3 : w/ Lane Departure Alert | *12 : From Oct. 2016 Production |
| * 4 : w/ Pre-Crash Safety System | until Mar. 2017 Production |
| * 5 : 1NR-FE | *13 : 1ND-TD |
| * 8 : Before Oct. 2016 Production | *14 : 1KR-FE |
| * 9 : From Oct. 2016 Production | *15 : Before May 2018 Production |
| *10 : Before Mar. 2017 Production | *16 : From May 2018 Production |
| *11 : From Mar. 2017 Production | *17 : From Mar. 2017 Production |
| | until May 2018 Production |

Lane Departure Alert and Pre-Crash Safety System

* 6 : w/ Stop & Start System
* 7 : w/o Stop & Start System



YARIS (EM1779E)