



























Position of Parts in Engine Compartment <LHD 1ND-TV TMMF Made>



- A 1 Headlight Unit RH
- A 2 Headlight Unit LH
- A 5 Headlight Unit RH
- A 6 Headlight Unit LH
- A 7 Headlight Unit RH
- A 8 Headlight Unit LH
- A 9 Fog Light Assembly RH
- A 10 Fog Light Assembly LH
- A 13 Low Pitched Horn Assembly
- A 15 Windshield Wiper Motor Assembly
- A 20 Front Airbag Sensor
- A 21 Cooling Fan Motor
- A 22 Cooling Fan Resistor
- A 23 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
- A 24 Ambient Temperature Sensor (Thermistor Assembly)
- A 27 Fuel Sedimentary Level Warning Switch (Fuel Sedimenter Element Sub-Assembly)
- A 28 Intake Mass Air Flow Meter Sub-Assembly
- A 29 Heater Assembly
- A 30 Fuel Pump Sub-Assembly
- A 31 Battery Current Sensor Assembly
- A 32 Engine Hood Courtesy Switch Assembly (Hood Lock Assembly)
- A 33 Vacuum Sensor Assembly
- A 34 Wireless Door Lock Buzzer
- A 49 Select Stroke Sensor
- A 59 ECM
- A 65 Fusible Link Block Assembly
- A 66 Fusible Link Block Assembly
- A 69 Headlight Unit RH
- A 70 Headlight Unit LH
- A 75 Front Speed Sensor RH
- A 76 Front Speed Sensor LH
- A 77 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Filler Cap Assembly)
- A 79 ABS & Traction Actuator Assembly
- A 80 Windshield Washer Motor and Pump Assembly
- A 81 Rear Washer Motor and Pump Assembly

Position of Parts in Engine Compartment <LHD 1ND-TV TMMF Made>



Position of Parts in Engine Compartment <LHD 1ND-TV TMMF Made>

