





















- * 6 : 1NR-FE
- * 8 : 1KR-FE
- *11 : Display Audio Type






B 23
Black




B 24
Black



B 33
Black




B 77
Gray




(Except 2ZR-FE)

B 77
Black



(2ZR-FE)


B 87
Black




B 88
Black




F 32
White




F 34
Black




F 35
Black




F 37
Black




F 38
White




F 39
White




F 41
Black




F 75
Black




F 82
Blue




F 83
Gray




F115
White



2B
White




2C
White




3A

White




3C

White




6A

White




7A

White




AF2

White



AF4

Gray



BA1

White

