





F47(C), F107(A), F108(B), F112(F), F118(N)
Radio Receiver Assembly
F109(D), F113(G), F114(H), F115(J), F116(K), F119(O)
Radio & Display Receiver Assembly




- * 3 : w/ Stop & Start System
- * 4 : w/o Stop & Start System
- * 5 : w/ Parking Assist (Rear View Monitor)
- * 8 : Display Audio Type
- * 9 : Except Display Audio Type
- *12 : Before Apr. 2012 Production
- *13 : From Apr. 2012 Production

B(*3)

B(*3)

F47(C), F107(A), F108(B), F112(F), F118(N)
Radio Receiver Assembly
F109(D), F113(G), F114(H), F115(J), F116(K), F119(O)
Radio & Display Receiver Assembly



F53
No. 1 Stereo Jack Adapter Assembly


- * 3 : w/ Stop & Start System
- * 8 : Display Audio Type
- * 9 : Except Display Audio Type
- *11 : w/ Microphone
- *12 : Before Apr. 2012 Production
- *13 : From Apr. 2012 Production
- *14 : w/ Stereo Jack Adapter

: There is no wire color information.

B(*3)


B(*3)


F47(C), F107(A), F108(B), F112(F), F118(N)
Radio Receiver Assembly
F109(D), F113(G), F114(H), F115(J), F116(K), F119(O)
Radio & Display Receiver Assembly




F47(C), F107(A), F108(B), F112(F), F118(N)
Radio Receiver Assembly
F109(D), F113(G), F114(H), F115(J), F116(K), F119(O)
Radio & Display Receiver Assembly


P9
Rear Television Camera Assembly




















- * 1 : LHD CVT
- * 2 : Except LHD CVT
- * 3 : w/ Stop & Start System
- * 4 : w/o Stop & Start System
- * 8 : Display Audio Type
- *15 : Before May 2012 Production














F 41
Black




F 47
White




F 53
Black




F 75
Black




F 76
White



F 82
Blue




F 83
Gray




F 91
White




F 92
White




F 95
White




F107
Green




F108
Green



















F109
White




F112
Gray







AF3
Black




AF4
Gray






BA1
White




GF1
White






KF1

White




KF2

White




KF3

White



OK1

White



OP1

White

