


Position of Parts in Body <LHD>



- K 1 Front Door Courtesy Light Switch Assembly LH
- K 2 Front Door Courtesy Light Switch Assembly RH
- K 3 Rear Door Courtesy Light Switch Assembly LH
- K 4 Rear Door Courtesy Light Switch Assembly RH
- K 5 Rear Combination Light Assembly LH
- K 6 Rear Combination Light Assembly RH
- K 7 No. 1 Luggage Compartment Light Assembly
- K 8 Front Seat Inner Belt Assembly RH
- K 9 Front Seat Inner Belt Assembly LH
- K 11 Door Control Receiver
- K 12 Electrical Key Antenna
- K 15 Stereo Component Amplifier Assembly
- K 17 Noise Filter
- K 18 Side Airbag Sensor Assembly LH
- K 19 Side Airbag Sensor Assembly LH
- K 20 Side Airbag Sensor Assembly RH
- K 21 Side Airbag Sensor Assembly RH
- K 22 No. 2 Side Airbag Sensor Assembly LH
- K 23 No. 2 Side Airbag Sensor Assembly RH
- K 24 Front Seat Outer Belt Assembly LH
- K 25 Front Seat Outer Belt Assembly RH
- K 26 Curtain Shield Airbag Assembly LH
- K 27 Curtain Shield Airbag Assembly RH
- K 28 Front Seat Airbag Assembly LH
- K 29 Front Seat Airbag Assembly RH
- K 36 Battery Thermometer Sensor
- K 37 Rear Combination Light Assembly LH
- K 38 Rear Combination Light Assembly RH
- K 39 Tire Pressure Warning ECU and Receiver (Tire Pressure Monitor Receiver Assembly)
- K 40 No. 2 Side Airbag Sensor Assembly LH
- K 41 No. 2 Side Airbag Sensor Assembly RH
- K 42 Rear Seat 3 Point Type Belt Assembly Outer RH
- K 43 Rear Seat 3 Point Type Belt Assembly Outer LH

Position of Parts in Body <LHD>

