





















Position of Parts in Instrument Panel <RHD>



- F 52 Windshield Wiper Relay Assembly
- F 53 Automatic Light Control Sensor
- F 54 Cooler (Solar Sensor) Thermistor
- F 55 Power Management Control ECU or Hybrid Vehicle Control ECU Assembly
- F 56 Power Management Control ECU or Hybrid Vehicle Control ECU Assembly
- F 57 Main Body ECU
- F 58 Double Lock Door Control Relay Assembly
- F 59 ECO Switch Assembly
- F 60 Pattern Select Switch Assembly
- F 62 Junction Connector
- F 63 Junction Connector
- F 64 Junction Connector
- F 65 Junction Connector
- F 66 Radio Receiver Assembly
- F 67 Radio & Display Receiver Assembly
- F 68 Radio & Display Receiver Assembly
- F 69 Radio & Display Receiver Assembly
- F 70 Radio & Display Receiver Assembly
- F 71 Radio & Display Receiver Assembly
- F 72 Navigation ECU
- F 73 Outer Mirror Switch Assembly
- F 74 Outer Mirror Switch Assembly
- F 75 Shift Position Indicator (Indicator Light Wire Sub-Assembly)
- F 76 Radio & Display Receiver Assembly
- F 77 Transponder Key Coil
- F 78 VSC Off Switch
- F 79 ECO Switch Assembly
- F 80 Radio & Display Receiver Assembly
- F 81 Tire Pressure Warning Reset Switch (No. 1 Tire Pressure Warning Switch)
- F 82 Double Lock Door Control Relay Assembly
- F 83 Pre-Crash System Cancel Switch Assembly
- F 84 Auto High Beam Switch
- F 85 Pre-Crash Safety City Buzzer
- F 86 Certification ECU
- F 87 Certification ECU
- F 88 Certification ECU
- F 89 Network Gateway ECU
- F 90 Junction Connector
- F 91 ECO Switch Assembly
- F 92 Diode (Shift Position Indicator)
- F 93 Lane-Keeping Assist Main Switch
- F 94 Pre-Crash System Cancel Switch Assembly
- F 95 Auto High Beam Switch
- F 96 Main Body ECU
- F 97 DLC3
- F 98 Lane-Keeping Assist Main Switch
- F 99 Pre-Crash System Cancel Switch Assembly
- F 100 Auto High Beam Switch

Position of Parts in Instrument Panel <RHD>



A diagram of a 2x2 grid with numbers 4, 1, 3, and 2. The grid is surrounded by a complex, multi-layered border. The numbers are arranged as follows:

4	1
3	2

A diagram of a 10-pin D-sub connector. It shows a top-down view of the connector housing with ten pins arranged in a single row. The pins are numbered 1 through 10 from left to right. The connector has a D-shaped shield on the left side and a mounting tab on the right side.

The diagram shows a 28-pin DIP package. Below the package is a 3x10 grid of pins, numbered 1 through 28. The pins are arranged in three rows: the first row contains pins 1-10, the second row contains pins 11-20, and the third row contains pins 21-28. Pins 16 and 24 are missing, creating a gap in the middle of the bottom row. Above the package is a component symbol consisting of a rectangle with a trapezoidal shape on top, representing the package body and pins.

A diagram of a five-digit lock mechanism. It features a horizontal row of five rectangular buttons, each labeled with a digit: 1, 2, 3, 4, and 5. Above this row is a complex assembly of levers and a central vertical component, likely representing the internal mechanical structure of the lock.

The diagram shows a cross-section of a 16-bit ALU. At the bottom, there is an 8-bit register with eight cells, each containing a number from 1 to 8. Above the register, there are several horizontal bars representing internal circuitry or data paths. The entire structure is enclosed in a rectangular frame.

A diagram of a 10-pin D-sub connector. The connector has a D-shaped body with a notch on the top. Inside, there are two rows of pins. The top row has 5 pins numbered 1 to 5 from left to right. The bottom row has 5 pins numbered 6 to 10 from left to right. The pins are arranged in a standard D-sub layout.

A diagram of a two-chambered heart, such as that of a fish. It shows a central vertical structure with two chambers, labeled 1 and 2, separated by a septum. The heart is connected to a network of blood vessels.

A diagram of a 12-key numeric keypad layout. The keypad is rectangular with rounded corners. It features a central function key labeled 'F' with a small square icon. Below the function key is a row of 12 numbered keys arranged in two rows of six. The top row contains keys 1 through 7, and the bottom row contains keys 8 through 12. The keys are arranged in a grid with a central column of three keys (F, 5, 10) and a central row of three keys (F, 5, 10).

A diagram of a standard 4-pin RJ45 connector. The connector is shown from a top-down perspective, highlighting the four pins used for data transmission. The pins are numbered 1, 2, 3, and 4 from left to right. The diagram is a simple line drawing with no shading.

A diagram of a balance scale. It has a central vertical beam with a horizontal bar across the middle. Two pans are suspended from the ends of the beam. The left pan is labeled '1' and the right pan is labeled '2'. The scale is shown in a simplified, schematic style.


A detailed diagram of a 30-pin connector layout, likely for a SCSI or similar interface. The connector is shown from a top-down perspective, with pins numbered 1 through 30. The layout is symmetrical around a central vertical axis. Pins 1-3 are on the left, 4-6 on the right, 7-9 on the left, 10-12 on the right, 13-15 on the left, 16-18 on the right, 19-21 on the left, 22-24 on the right, 25-27 on the left, and 28-30 on the right. The diagram shows the physical arrangement of the pins and the internal wiring connections between them.

A detailed diagram of a 28-pin DIP package. The package is rectangular with a central notch. Pins are numbered 1 through 28 in a standard sequence: 1-4 on the top edge, 5-16 on the second edge from the top, 17-28 on the bottom edge, and 29-40 on the fourth edge from the top. The diagram shows the physical layout of the pins and the package body.


A top-down diagram of a bus interior showing a 2x18 seating arrangement. The seats are numbered 1 through 18 in two rows. The front row (top) contains seats 1, 3, 4, 5, 6, 7, 8, 9, 10, 17, and 18. The back row (bottom) contains seats 2, 11, 12, 13, 14, 15, 16, and 18. There are two exits at the front of the bus, one on each side of the aisle. There is also an exit at the back of the bus, centered between the two rows of seats. The bus has a driver's seat on the left side of the front. There are two sets of doors on the left side of the bus, one near the front and one near the back. There are also two sets of doors on the right side of the bus, one near the front and one near the back. The bus is shown from a top-down perspective, with the front of the bus at the top of the diagram.

Position of Parts in Instrument Panel <RHD>


F 89
Black



F 90
White




F 91
White




F 92
White




F 93
White




F 94
Gray




F 95
Black




F 96
White




F 97
White



F 98
Blue



F 99
Black



F100
White

