TOYOTA
SERVICE BULLETIN
Group: 12 No.: 05 Date: Feb 11

Yaris NCP90 / 91 / 93

Changes to Repair Manual SC00S5E (Aug 05 – Jul 08)


Changes have been made to Yaris Repair Manual SC00S5E with production period Aug 05 to Jul 08.

Publication	Section	Title	Paragraph
SC00S5E	Lighting	Headlight Assembly (for Hatchback)	Reassembly

Changes follow on from this page. Changes are indicated by an arrow.

Please copy and file these pages with the above Repair Manual.

© 2011 Toyota Motor Corporation Australia Limited A.B.N. 64 009 686 097
All rights reserved. This material may not be reproduced or copied, in whole or part, without the written permission of Toyota Motor Corporation Australia Limited, 155 Bertie Street, Port Melbourne, Victoria.



REASSEMBLY


1. INSTALL HEADLIGHT LEVELING MOTOR (w/ Headlight Leveling)

(a) Engage the leveling motor tip with the reflector.


NOTICE:
While pushing and pulling the leveling motor forwards and backwards, confirm that the reflector moves together with the leveling motor.

[Added]

[Added]



(b) Turn the headlight leveling motor in the direction shown in the illustration to install it.




2. INSTALL FRONT TURN SIGNAL LIGHT BULB

(a) Install the front turn signal light bulb into the light socket.

(b) Turn the front turn signal light bulb socket and bulb, in the direction indicated by the arrow in the illustration, to install them.

3. INSTALL CLEARANCE LIGHT BULB

(a) Install the clearance light bulb into the light socket.



(b) Turn the clearance light bulb socket and bulb, in the direction indicated by the arrow in the illustration, to install them.

© 2011 Toyota Motor Corporation Australia Limited A.B.N. 64 009 686 097
All rights reserved. This material may not be reproduced or copied, in whole or part, without the written permission of Toyota Motor Corporation Australia Limited, 155 Bertie Street, Port Melbourne, Victoria.