
F RELAY LOCATIONS

[Engine Room R/B and Engine Room J/B Inner Circuit]

* 1:1KR-FE
* 2:1NZ-FE, 2NZ-FE, 2SZ-FE, 2ZR-FE
* 4:1ND-TV



* 5:w/ Daytime Running Light
* 6:w/o Daytime Running Light

