# [Fusible Link Block Inner Circuit]
# (Diesel)

* 1:Multi-mode Manual Transmission
* 2:Except Multi-mode Manual Transmission

**A27(B), A28(A), C30(C), C66(D)**
Fusible Link Block

