[Fusible Link Block Inner Circuit]
(Gasoline)

* 1:Multi-mode Manual Transmission
* 2:Except Multi-mode Manual Transmission

A27(B), A28(A), C30(C)
Fusible Link Block

