


JX1
Front Door RH Wire
Seat Airbag RH Wire
FR1
Electrical Key Wire RH
MJ1
J1
Roof Wire
Rear Window No.1 Wire
Front Door LH Wire
O1
GS1
ZJ1
Electrical Key Wire LH
Back Door No.2 Wire
Floor Wire
N1
Skid Control Sensor RH Wire
JY1
Seat Airbag LH Wire
J2
aJ1
Skid Control Sensor LH Wire
LJ1
Back Door No.1 Wire
Luggage Room No.2 Wire
MN1


FR1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
GS1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
JX1
White
1 2
2 1
JY1
White
1 2
2 1
LJ1
White
1 2 3 4 5
6 7 8 9 10
5 4 3 2 1
10 9 8 7 6
MJ1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
MN1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
ZJ1
White
1 2
2 1
aJ1
White
1 2
2 1