


Front Door RH Wire
JX1
Seat Airbag RH Wire
FR1
MJ1
Electrical Key Wire RH
J1
Rear Window No.1 Wire
O1
ZJ1
Back Door No.2 Wire
N1
MN1
Skid Control Sensor RH Wire
Roof Wire
Front Door LH Wire
GS1
Floor Wire
Electrical Key Wire LH
JY1
Seat Airbag LH Wire
aJ1
Skid Control Sensor LH Wire
J2
LJ1
Luggage Room No.2 Wire
Back Door No.1 Wire


FR1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
GS1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
JX1
White
1 2
2 1
JY1
White
1 2
2 1
LJ1
White
1 2 3 4 5
6 7 8 9 10
5 4 3 2 1
10 9 8 7 6
MJ1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
MN1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
ZJ1
White
1 2
2 1
aJ1
White
1 2
2 1