

(*5)
(*6)
J34
J31
J23
J1
J20
J16
J39
J22
* 5:w/ Curtain Shield Airbag
* 6:w/o Curtain Shield Airbag
* 7:2ZR-FE
* 8:Except 2ZR-FE
J32
J14
(*7)
J52
(*8)
J3
J13
J37
J38
J35
J2
J21
J40
(*6)
J17
(*5)
J15
J33
J12
J30
J5
J29
J28
J36
J4
(*8)
J53
(*7)

J 1 Door Courtesy SW (Front RH)
J 2 Door Courtesy SW (Front LH)
J 3 Rear Combination Lamp (RH)
J 4 Rear Combination Lamp (LH)
J 5 Fuel Suction Pump and Gage Assembly
J 12 Room Lamp (Luggage)
J 13 Door Control Receiver
J 14 Airbag Sensor (Rear RH)
J 15 Airbag Sensor (Rear LH)
J 16 Side Airbag Sensor (RH)
J 17 Side Airbag Sensor (LH)
J 20 Pretensioner (RH)
J 21 Pretensioner (LH)
J 22 Curtain Shield Airbag Squib (RH)
J 23 Curtain Shield Airbag Squib (LH)
J 28 Junction Connector
J 29 Junction Connector
J 30 Diode (Room Lamp)
J 31 Noise Filter (Rear Window Defogger)
J 32 Door Courtesy SW (Rear RH)
J 33 Door Courtesy SW (Rear LH)
J 34 Front Seat Inner Belt (RH)
J 35 Front Seat Inner Belt (LH)
J 36 Electrical Key Oscillator (Inside Luggage Room)
J 37 Electrical Key Oscillator (Outside Luggage Room)
J 38 License Plate Lamp
J 39 Side Airbag Sensor (RH)
J 40 Side Airbag Sensor (LH)
J 52 Rear Combination Lamp (RH)
J 53 Rear Combination Lamp (LH)


J 1
White




J 2
White



J 3
White



J 4
White




J 5
White




J 12
White




J 13
White




J 14
Yellow




J 15
Yellow




J 16
Yellow




J 17
Yellow




J 20
Yellow




J 21
Yellow




J 22
Black




J 23
Black



J 28
White




J 29
White



J 30
Black



J 31
White




J 32
White




J 33
White




J 34
White




J 35
White



J 36
White




J 37
White




J 38
Black



J 39
Yellow



J 40
Yellow



J 52
White



J 53
White

