



JX1
Front Door RH Wire
Seat Airbag RH Wire
FR1
MJ1
Electrical Key Wire RH
HJ1
Rear Door No.1 Wire
J1
Roof Wire
Front Door LH Wire
Rear Window No.1 Wire
O1
GS1
ZJ1
Electrical Key Wire LH
Back Door No.2 Wire
IJ1
N1
JY1
MN1
Floor Wire
Skid Control Sensor RH Wire
Seat Airbag LH Wire
Rear Door No.2 Wire
aJ1
Skid Control Sensor LH Wire
J2
LJ1
Back Door No.1 Wire
Luggage Room No.2 Wire


FR1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
GS1
Gray
1 2 3 4
5 6 7 8
4 3 2 1
8 7 6 5
HJ1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
IJ1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
JX1
White
1 2
2 1
JY1
White
1 2
2 1
LJ1
White
1 2 3 4 5
6 7 8 9 10
5 4 3 2 1
10 9 8 7 6


MJ1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
MN1
White
1 2 3 4 5
6 7 8 9
10 11 12 13 14 15 16 17
5 4 3 2 1
9 8 7 6
17 16 15 14 13 12 11 10
ZJ1
White
1 2
2 1
aJ1
White
1 2
2 1