


A26
A38
A19
A37
A17
E10
E12
E16
E1
* 7:Automatic A/C
* 8:Manual A/C
E4
E17
E3
A13
A16
A48
A20
E9
E11
(*7)
E8
(*8)
E2
E5
E6


A 13 Stop Lamp SW
A 16 Clutch Start SW
A 17 PTC Heater
A 19 Power Steering ECU
A 19 Power Steering ECU
A 20 Accelerator Position Sensor
A 26 Junction Connector
A 37 Multi-mode Manual Transmission ECU
A 38 Multi-mode Manual Transmission ECU
A 48 Clutch Start SW (No.2)

E 1 Blower SW
E 2 A/C Thermistor No.1
E 3 Blower Resistor
E 4 Blower Motor
E 5 A/C SW
E 6 Rear Window Defogger SW
E 8 A/C Amplifier
E 9 A/C Amplifier
E 10 Junction Connector
E 11 A/C Amplifier
E 12 A/C Room Temp. Sensor
E 16 A/C Control Assembly
E 17 Blower Motor


A 13
White




A 16
Black



A 17
White




A 19
Gray




(TMC Made From Aug. 2007 Production)

A 19
Gray




(Except TMC Made From Aug. 2007 Production)


A 20
Black




A 26
Black




A 37
White




A 38
White




A 48
White




E 1
White




E 2
White




E 3
Black




E 4
Black




E 5
White



E 6
White




E 8
White




(H/B, S/D Before Aug. 2007 Production)


E 9
White




E 10
White




E 11
White



E 12
Black



E 16
White



E 17
Black

