


C91
C46
C85
C47
C48
C87
C82
C53
C54
C66
C30
C83
C65
C18
C45
C88
C64
C89
C56
C99
C16
C63
C62
C61
e5
e6
C77
C10
C9
C8
C17
C93
C15
C90
d2
C86
C84
C92
C100
C19
C80
C79
C81

C 8 A/C Compressor
C 9 Alternator
C 10 Alternator
C 15 Starter
C 16 Engine Oil Pressure SW
C 17 Throttle Body Assembly
C 18 Camshaft Position Sensor
C 19 Water Temp. Sensor
C 30 Fusible Link Block
C 45 Injector No.1
C 46 Injector No.2
C 47 Injector No.3
C 48 Injector No.4
C 53 VSV (Pressure Release Valve)
C 54 Magnetic Proportional Valve
C 56 Fuel Pressure Sensor
C 61 Shift Actuator
C 62 Select Actuator
C 63 Fuel Temp. Sensor
C 64 Glow Plug
C 65 Glow Plug Relay
C 66 Fusible Link Block
C 77 Back-Up Lamp SW
C 79 Clutch Stroke Sensor
C 80 Clutch Actuator
C 81 Transmission Revolution Sensor
C 82 Turbocharger Sub-Assembly
C 83 Engine ECU
C 84 Turbo Pressure Sensor
C 85 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C 86 EGR Valve Control Motor
C 87 Turbocharger Sub-Assembly
C 88 Exhaust Gas Temperature Sensor
C 89 No.2 Exhaust Gas Temperature Sensor
C 90 Diesel Turbo Inlet Air Temperature Sensor
C 91 Differential Pressure Sensor
C 92 VSV (EGR)
C 93 Oil Level Sensor
C 99 Crankshaft Position Sensor
C 100 Crankshaft Position Sensor

d 2 Starter

e 5 Neutral Start SW
e 6 Shift Stroke Sensor


C 8
Gray



C 9
Black



C 10



(Except 2SZ-FE)


C 15
Black



C 16
Gray



C 17
Black




C 18
Black




C 19
Black




C 30




C 45
Black




C 46
Brown




C 47
Black




C 48
Brown




C 53
Black



C 54
Black



C 56
Black




C 61
Black




C 62
Black



C 63
Black




C 64




C 65
Gray



C 66
Black



C 77
Gray




C 79
Black




C 80
Black




C 81
Black




C 82
Black



C 83
Black




C 84
Black



C 85
Black



C 86
Black



C 87
Black



C 88
Dark Gray




C 89
Gray




C 90
Gray




C 91
Black



C 92
Blue



C 93
Gray




C 99
Gray




C100
Black



d 2



e 5
Black



e 6
Black

