

* 1:Before Aug. 2008 Production
* 2:From Aug. 2008 Production
* 3:Before Aug. 2010 Production
* 4:From Aug. 2010 Production
J23
J50
J1
J13
J51
J34
(*1)
J35
J2
J21
J17
(*3)
J60
(*4)
J22
J45
J12
J32
J41
J48
(*4)
J57
J43
J49
J54
(*2)
J33
J58
(*4)
J15
(*3)
J20
J29
J28
J59
(*4)
J5
J16
(*3)
J42
J46
J30
J47
J14
(*3)
J44

J 1 Door Courtesy SW (Front RH)
J 2 Door Courtesy SW (Front LH)
J 5 Fuel Suction Pump and Gage Assembly
J 12 Room Lamp (Luggage)
J 13 Door Control Receiver
J 14 Airbag Sensor (Rear RH)
J 15 Airbag Sensor (Rear LH)
J 16 Side Airbag Sensor (RH)
J 17 Side Airbag Sensor (LH)
J 20 Pretensioner (RH)
J 21 Pretensioner (LH)
J 22 Curtain Shield Airbag Squib (RH)
J 23 Curtain Shield Airbag Squib (LH)
J 28 Junction Connector
J 29 Junction Connector
J 30 Diode (Room Lamp)
J 32 Door Courtesy SW (Rear RH)
J 33 Door Courtesy SW (Rear LH)
J 34 Front Seat Inner Belt (RH)
J 35 Front Seat Inner Belt (LH)
J 41 Rear Combination Lamp (RH)
J 42 Rear Combination Lamp (LH)
J 43 License Plate Lamp (RH)
J 44 License Plate Lamp (LH)
J 45 Speaker (Rear RH)
J 46 Speaker (Rear LH)
J 47 Center Stop Lamp
J 48 Center Stop Lamp
J 49 Door Lock Assembly (Luggage)
J 50 Rear Window Defogger
J 51 Noise Filter (Rear Window Defogger)
J 54 Front Seat Inner Belt (RH)
J 57 Airbag Sensor (Rear RH)
J 58 Airbag Sensor (Rear LH)
J 59 Side Airbag Sensor (RH)
J 60 Side Airbag Sensor (LH)

J 1
White



J 2
White




J 5
White




J 12
White




J 13
White




J 14
Yellow




J 15
Yellow




J 16
Yellow




J 17
Yellow




J 20
Yellow




J 21
Yellow




J 22
Black




J 23
Black



J 28
White



J 29
White



J 30
Black




J 32
White




J 33
White




J 34
White




J 35
White




J 41
White




J 42
White




J 43
Gray




J 44
Gray



J 45
White




J 46
White




J 47
Gray



J 48
White




J 49
Black




J 50
Black




J 51
White




J 54
White




J 57
Yellow



J 58
Yellow



J 59
Yellow



J 60
Yellow

