
■MANUAL HEADLIGHT BEAM LEVEL CONTROL SYSTEM

- The manual headlight beam level control system is newly provided as standard equipment on the Europe models.
- This system keeps the beam of the headlight adjusted to the appropriate level in accordance with the number (weight) of passengers and volume of luggage. The headlight beam level can be adjusted from 0 to 5 by operating the headlight beam level control switch.



00SBE03Y

Hatchback Models