
■CLUTCH START SYSTEM

1. General


This system prevents the starter from cranking unless the clutch pedal is depressed. When the engine is started with the shift lever in a positon other than N, it helps ensure safety by preventing the vehicle from moving unintentionally.

2. Layout of Main Components



Hatchback LHD Model

3. System Diagram



*: See page BE-60 for vehicles equipped with the smart entry & start system.