■FUEL SYSTEM

1. General

- 12-hole type injectors are used in the unleaded gasoline models, and 4-hole type injectors are used in the leaded gasoline models.
- A quick connector is used to connect the fuel pipe with the fuel hose for excellent serviceability.
- A fuel tank made of multi-layer plastic is used. For details, see page EG-21 in the 1KR-FE engine section.
- The charcoal canister is combined with the fuel pump for a lightweight construction. For details, see page EG-22 in the 1KR-FE engine section.
- The fuel returnless system is used to reduce evaporative emissions. For details, see page EG-23 in the 2SZ-FE engine section.
- A fuel cut control is used to stop the fuel pump when the SRS driver's and front passenger's airbags are deployed. For details, see page EG-55 in the 1KR-FE engine section.

