■FUNCTION

The theft deterrent system has the following functions:

Function	Outline
Alarm	When the theft deterrent system is switched to the alarm state, the warning item is operated for approximately 30.0 seconds and the alarm sounds.
Alarm Indicator	● When the theft deterrent system is switched to the armed preparation or alarm state, the security indicator light is illuminated. ● When the theft deterrent system is switched to the armed state, the security indicator light is flashed.
Forced Door Lock	● The main body ECU transmits a door lock signal to all the doors when all the following conditions are satisfied. – The theft deterrent system is in the alarm state. – Any door is changed from “lock” to “unlock” through an operation other than the entry unlock function. ● The function stops when one of the following conditions is met. – All doors are locked. – The warning ends after approximately 30.0 seconds.