





























- C 8 A/C Compressor
- C 9 Alternator
- C 10 Alternator
- C 15 Starter
- C 16 Engine Oil Pressure SW
- C 19 Water Temp. Sensor
- C 22 Back-Up Lamp SW
- C 26 Air Flow Meter
- C 30 Fusible Link Block
- C 44 Crankshaft Position Sensor
- C 45 Injector No.1
- C 46 Injector No.2
- C 47 Injector No.3
- C 48 Injector No.4
- C 49 Camshaft Position Sensor
- C 50 Engine ECU
- C 51 Oil Level Sensor
- C 52 EGR Valve Control Motor
- C 53 VSV (Pressure Release Valve)
- C 54 Magnetic Proportional Valve
- C 55 VSV (EGR)
- C 56 Fuel Pressure Sensor
- C 57 ISC Valve
- C 58 Throttle Position Sensor
- C 59 Shift Stroke Sensor
- C 60 Select Stroke Sensor
- C 61 Shift Actuator
- C 62 Select Actuator
- C 63 Fuel Temp. Sensor
- C 64 Glow Plug
- C 65 Glow Plug Relay
- C 66 Fusible Link Block


- d 1 Starter




(Except 2ZR-FE From Aug. 2008 Production)




C 63
Black




C 64



C 65
Gray



C 66
Black



d 1

