































Position of Parts in Body <RHD 4-Door>

- * 1: Before Aug. 2008 Production
- * 2: From Aug. 2008 Production
- * 3: Before Aug. 2010 Production
- * 4: From Aug. 2010 Production




- J 1 Door Courtesy SW (Front RH)
- J 2 Door Courtesy SW (Front LH)
- J 5 Fuel Suction Pump and Gage Assembly
- J 12 Room Lamp (Luggage)
- J 13 Door Control Receiver
- J 14 Airbag Sensor (Rear RH)
- J 15 Airbag Sensor (Rear LH)
- J 16 Side Airbag Sensor (RH)
- J 17 Side Airbag Sensor (LH)
- J 20 Pretensioner (RH)
- J 21 Pretensioner (LH)
- J 22 Curtain Shield Airbag Squib (RH)
- J 23 Curtain Shield Airbag Squib (LH)
- J 28 Junction Connector
- J 29 Junction Connector
- J 30 Diode (Room Lamp)
- J 32 Door Courtesy SW (Rear RH)
- J 33 Door Courtesy SW (Rear LH)
- J 34 Front Seat Inner Belt (RH)
- J 35 Front Seat Inner Belt (LH)
- J 41 Rear Combination Lamp (RH)
- J 42 Rear Combination Lamp (LH)
- J 43 License Plate Lamp (RH)
- J 44 License Plate Lamp (LH)
- J 45 Speaker (Rear RH)
- J 46 Speaker (Rear LH)
- J 47 Center Stop Lamp
- J 48 Center Stop Lamp
- J 49 Door Lock Assembly (Luggage)
- J 50 Rear Window Defogger
- J 51 Noise Filter (Rear Window Defogger)
- J 54 Front Seat Inner Belt (RH)
- J 57 Airbag Sensor (Rear RH)
- J 58 Airbag Sensor (Rear LH)
- J 59 Side Airbag Sensor (RH)
- J 60 Side Airbag Sensor (LH)

Position of Parts in Body <RHD 4-Door>



J 59
Yellow



J 60
Yellow

