



Position of Parts in Instrument Panel <LHD H/B>




- D 95 ECO Run Cancel Switch Assembly
- D 96 Engine Stop and Start ECU
- D 97 Passenger Seat Belt Warning Lamp
- D 98 Engine Stop and Start ECU
- D 99 Multi-mode Manual Transmission ECU
- D 100 Transmission Shift Main SW
- D 101 Navigation Receiver Assembly
- D 102 Junction Connector
- D 103 Junction Connector
- D 104 Cooler Thermistor
- D 105 Junction Connector
- D 108 Junction Connector
- D 109 Junction Connector
- D 110 Junction Connector


D 95
Black




D 96
White




D 97
White




D 98
White




D 99
White




D100
White




D101
Gray




D102
White




D103
White




D104
Black




D105
White



D108
White



D109
White



D110
White

