Steering Gearbox

Illustrated Index

CAUTION:
- Before disassembling the gearbox, wash it off with solevent and a brush.
- Thorougly clean all disassembled parts.
- Replace parts with damaged sliding surfaces or deterioration.
- Do not try to disassemble the gearbox assembly.If the gearbox is faulty, replace the whole gearbox as an assembly.

NOTE: RH Drive shown, LH Drive is similar.