
MAIN FUSE BOX
FUSIBLE LINK BLK
SBF-4 FUSE 45A
NCA
WHT
WHT
F38
BLK/YEL
F36
COMBINATION METER
CHARGE INDICATOR
IGNITION SWITCH
OFF
ACC
ON
START
BLK/WHT
I10
RED/BLK
I14
RED
RED
B52
BATTERY
FUSE & RELAY BOX
FUSE 15 10A
DAYTIME RUNNING LIGHT CONTROL MODULE
STARTER MOTOR
I5
GENERATOR
107676