Position of Parts in Instrument Panel <LHD>



H 1 Certification ECU Assembly
H 2 Certification ECU Assembly
H 3 Power Management Control ECU
H 4 Power Management Control ECU
H 5 Driving Support ECU Assembly
H 6 Seat Belt Control ECU
H 7 Seat Belt Control ECU
H 12 Lower No. 2 Instrument Panel Airbag Assembly
H 13 Blower with Fan Motor Sub-Assembly
H 14 No. 1 Interior Illumination Light Assembly RH
H 15 Glove Box Light Assembly
H 16 Main Body ECU
H 17 Main Body ECU
H 18 Main Body ECU
H 19 Combination Meter Assembly
H 22 ID Code Box
H 23 No. 1 Clearance Warning Buzzer
H 24 Skid Control Buzzer Assembly
H 25 Power Steering ECU Assembly

H 1
White



H 2
White



H 3
Gray



H 4
Gray



H 5
White



H 6
White



H 7
White



H 12
Yellow



H 13
Black



H 14
Gray



H 15
Gray



H 16
Black



H 17
White



H 18
White



H 19
White



H 22
White



H 23
Black



H 24
Blue



H 25
White