
* 1:FMVSS138 Type
* 2:ECE-R64 Type
(*2)
(*1)
P16
P25
P29
P17
P18
P22
P30
P34
P13
P11
P14
P3
P4
P24
P21
P5
P8
P15
P26
P6
P38
P35
P37
P7
P23
P31
P33
P32

P 3 Front Door Courtesy Light Switch Assembly LH
P 4 Side Airbag Sensor Assembly LH
P 5 Front Seat Outer Belt Assembly LH
P 6 No. 1 Indoor Electrical Key Antenna Assembly (Rear Floor)
P 7 Fuel Suction Tube with Pump & Gage Assembly
P 8 Rear Door Courtesy Light Switch Assembly LH
P 11 Rear Window Shade Assembly
P 13 Center Stop Light Set
P 14 No. 1 Luggage Compartment Light Assembly
P 15 Noise Filter (No. 1 Luggage Compartment Light Assembly and Center Stop Light Set)
P 16 Curtain Shield Airbag Assembly LH
P 17 Noise Filter (Rear Window Defogger)
P 18 Rear Window Defogger (Back Window Glass)
P 21 Front Seat Outer Belt Assembly LH
P 22 Rear Seat 3 Point Type Belt Assembly Outer LH
P 23 Rear Tire Pressure Monitor Initiator
P 24 Front Seat Outer Belt Assembly LH
P 25 Tire Pressure Warning ECU and Receiver (Tire Pressure Monitor Receiver Assembly)
P 26 Rear Airbag Sensor LH
P 29 Tire Pressure Warning ECU and Receiver (Door Control & Tire Pressure Monitoring System Receiver Assembly)
P 30 Door Control Receiver
P 31 Fuel Lid Lock with Motor Assembly
P 32 Rear Header Speaker Assembly LH
P 33 Diode (No. 1 Luggage Compartment Light Assembly)
P 34 Diode (Luggage Closer Motor Assembly)
P 35 Junction Connector
P 37 Rear Seat Inner Belt with Center Assembly LH
P 38 Diode (Rear Fog)

P 3
Black

P 4
Yellow



P 5
Yellow



P 6
White



P 7
White

P 8
White

P 11
White



P 13
White



P 14
White

P 15
Black



P 16
Black



P 17
Black



P 18
Black

P 21
White



P 22
Yellow



P 23
White



P 24
White



P 25
White



P 26
Yellow



P 29
White



P 30
Blue



P 31
Black



P 32
White



P 33
Black

P 34
Black

P 35
White



P 37
Black



P 38
Black