
A69
A27
A9
A17
A41
A29
A11
A10
A13
A42
A43
B4
A50
A74
A53
A55
A54
A21
A19
B5
B2
B1
A45
B14
B13
B12
B10
B9
B7
B8
A18
A24
A23
A22
A25
B6

A 9 Windshield Wiper Motor Assembly
A 10 Wireless Door Lock Buzzer
A 11 Front Tire Pressure Monitor Initiator
A 13 Brake Actuator Assembly
A 17 Front Absorber Control Actuator LH
A 18 Front Airbag Sensor LH
A 19 ECM
A 21 ECM
A 22 Level Warning Switch Assembly
A 23 Windshield Washer Motor and Pump Assembly
A 24 Headlight Cleaner Control Relay
A 25 Headlight Cleaner Motor and Pump Assembly
A 27 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
A 29 Power Steering ECU Assembly
A 41 No. 1 Wiring Harness Condenser Assembly
A 42 Front Absorber Control Actuator RH
A 43 Security Horn Assembly
A 45 Front Airbag Sensor RH
A 50 Junction Connector
A 53 Junction Connector
A 54 Junction Connector
A 55 Junction Connector
A 69 Junction Connector
A 74 Transmission Control ECU Assembly

B 1 Front Fog Light Assembly RH
B 2 Headlight Assembly RH
B 4 Cooling Fan ECU
B 5 Headlight Assembly LH
B 6 Front Fog Light Assembly LH
B 7 A/C Pressure Sensor (Liquid Tube Sub-Assembly)
B 8 Ambient Temperature Sensor (Thermistor Assembly)
B 9 Low Pitched Horn Assembly
B 10 Engine Hood Courtesy Switch
B 12 Millimeter Wave Radar Sensor Assembly
B 13 High Pitched Horn Assembly
B 14 Smog Ventilation Sensor

A 9
Black



A 10
Gray



A 11
Black



A 13
Black



A 17
Black



A 18
Yellow



A 19
White



A 21
White



A 22
Black



A 23
Black



A 24
Gray



A 25
Black



A 27
Gray

A 29
Black



A 41
Black



A 42
Black



A 43
Black

A 45
Yellow



A 50
Gray



A 53
Black



A 54
Black



A 55
Black



A 69
Gray



A 74
Black



B 1
Black



B 2
Black



B 4
Black



B 5
Black



B 6
Black



B 7
Black



B 8
Black

B 9
Black



B 10
Black



B 12
Black



B 13
Gray

B 14
Black