
A20
A22
A23
A12
A17
A16
A15
A14
A13
A45
A44
A18
A10
A11
A9
A65
A67
m2
A61
A66
m3
A4
A24
A28
A58
A27
A25
A68
n1
A26
z13
A52
z14
A1
A5
A3
A2

A 1 Airbag Sensor (Front LH)
A 2 Windshield Washer Motor
A 3 Headlamp Cleaner Motor
A 4 Water Level Warning SW
A 5 Headlamp Cleaner Control Relay
A 9 Junction Connector
A 10 Junction Connector
A 11 Junction Connector
A 12 Absorber Control Actuator (Front LH)
A 13 Skid Control ECU
A 14 Skid Control ECU
A 15 Skid Control ECU
A 16 Brake Actuator
A 17 Junction Connector
A 18 Wireless Door Lock Buzzer
A 20 Windshield Wiper Motor
A 22 Brake Stroke Simulator Cylinder
A 23 Brake Fluid Level Warning SW
A 24 Power Steering ECU
A 25 Fuel Pump Resistor
A 26 Airbag Sensor (Front RH)
A 27 Absorber Control Actuator (Front RH)
A 28 Security Horn
A 44 Short Connector (Brake Stroke Simulator Cylinder)
A 45 Short Connector (Brake Stroke Simulator Cylinder)
A 52 Front Stabilizer Control ECU
A 58 Noise Filter (Ghost Buster)
A 61 Transmission Control ECU
A 65 Junction Connector
A 66 Engine ECU
A 67 Engine ECU
A 68 Cooling Fan Relay

m 2 Speed Sensor (Front LH)
m 3 Height Control Sensor (Front)

n 1 Speed Sensor (Front RH)

z 13 Front Stabilizer Control ECU , Front Stabilizer Control Actuator Assembly
z 14 Front Stabilizer Control ECU , Front Stabilizer Control Actuator Assembly

A 1
Yellow



A 2
Black



A 3
Black

A 4
Black

A 5
Gray

A 9
White



A 10
Blue



A 11
Blue



A 12
Black



A 13
Black



A 14
Black



A 15
Gray



A 16
Black



A 17
Gray

A 18
Black

A 20
Gray

(LHD Before Sep. 2008 Production)

A 20
Black

(LHD From Sep. 2008 Production, RHD)

A 22
Gray

A 23
Gray

A 24
Black



A 25
Gray

(3UZ-FE)

A 26
Yellow



A 27
Black



A 28
Black

A 44
Gray



A 45
Gray

A 52
Black



A 58
Black



A 61
Black



A 65
Blue



A 66
White



A 67
White



A 68
Gray



m 2
Black

m 3
Black



n 1
Black

z 13
Black



z 14
Black