
K1
K2
h1
M2
M1
f1
* 1:3UZ-FE
* 3:Light Control SW RH Side Type
* 4:Light Control SW LH Side Type
W2
W3
W1
k1
(*1)
W16
V14
X1
V13
V35
e1
g1
(*4)
g1
(*3)
V1
V2

K	1	Airbag Squib (Front Passenger's Airbag Assembly)
K	2	Airbag Squib (Front Passenger's Airbag Assembly)
M	1	Automatic Light Control Sensor
M	2	Speaker (Center)
V	1	Body ECU (Cowl Side J/B RH)
V	2	Absorber Control ECU
V	13	Airbag Sensor Assembly Center
V	14	Power Outlet Socket
V	35	Electrical Key Oscillator (Console)
W	1	Body ECU (Cowl Side J/B LH)
W	2	Body ECU (Cowl Side J/B LH)
W	3	Body ECU (Cowl Side J/B LH)
W	16	Airbag Sensor Assembly Center
X	1	Console Box Lamp
e	1	A/C Amplifier , A/C Blower Assembly
f	1	Combination Meter , Telltale Lamp Assembly
g	1	Windshield Wiper SW Assembly , Headlamp Dimmer SW Assembly
h	1	Multi-Display , Multi-Media Module Navigation Assembly
k	1	Blower Motor

K 1
Black



K 2
Orange



M 1
Black



M 2
White



V 1
White



V 2
Black



V 13
Yellow



V 14
White



V 35
White



W 1
White



W 2
White



W 3
White



W 16
Yellow



X 1
White



e 1
White



f 1
White



g 1
White



h 1
White



k 1
White