F RELAY LOCATIONS

② : Engine Room R/B No.2	Engine Compartment Left (See Page 20)
⬭ : Engine Room J/B No.2	




Unit C
2D
(from Engine Room Main Wire)
2C
(from Engine Room Main Wire)
2B
(from Engine Room Main Wire)
2A
(from Engine Room Main Wire)
Black
2G
(from Engine Room No.2 Wire)
Black
2E
(from Engine Room Main Wire)
Black
2F
(from Engine Room Main Wire)
Unit A
Unit B

② : Engine Room R/B No.2	Engine Compartment Left (See Page 20)
⬭ : Engine Room J/B No.2	

Unit D