
B8
B4
A8
A56
A7
A19
A16
A15
A58
A18
A37
A31
A40
A41
A17
A10
A9
A6
A5
B12
A3
B2
B1
A57
B3
B10
B11
B9
B6
B7
B5
A12
A1
A2
A4
B13

A	1	Level Warning Switch Assembly
A	2	Headlight Cleaner Motor and Pump Assembly
A	3	Headlight Cleaner Control Relay
A	4	Windshield Washer Motor and Pump Assembly
A	5	ECM
A	6	ECM
A	7	Junction Connector
A	8	Junction Connector
A	9	Junction Connector
A	10	Junction Connector
A	12	Front Airbag Sensor LH
A	15	Junction Connector
A	16	Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Sub-Assembly)
A	17	Front Height Control Sensor Sub-Assembly LH
A	18	Wireless Door Lock Buzzer
A	19	Windshield Wiper Motor Assembly
A	31	Power Steering ECU Assembly
A	37	Security Horn Assembly
A	40	Fuel Pump Resistor
A	41	Front Airbag Sensor RH
A	56	A/C Pressure Sensor (Suction Pipe Sub-Assembly)
A	57	Noise Filter
A	58	Brake Actuator Assembly
B	1	Fog Light Assembly RH
B	2	Headlight Assembly RH
B	3	No. 2 Cooling Fan Motor
B	4	Cooling Fan Motor
B	5	Cooler (Ambient Temperature Sensor) Thermistor
B	6	Low Pitched Horn Assembly
B	7	A/C Pressure Sensor
B	8	Engine Hood Courtesy Switch
B	9	Millimeter Wave Radar Sensor Assembly
B	10	High Pitched Horn Assembly
B	11	Smog Ventilation Sensor
B	12	Headlight Assembly LH
B	13	Fog Light Assembly LH

A 1
Black

A 2
Black

A 3
Gray

A 4
Black



A 5
White



A 6
White



A 7
Blue



A 8
Blue



A 9
White



A 10
Gray



A 12
Yellow



A 15
White

A 16
Gray

A 17
Black



A 18
Black



A 19
Black

A 31
Black



A 37
Black



A 40
Black

A 41
Yellow



A 56
Black



A 57
Black



A 58
Black



B 1
Black



B 2
Black



B 3
Gray



B 4
Gray



B 5
Black

B 6
Black

B 7
Black



B 8
Black

B 9
Black

B 10
Gray



B 11
Black

B 12
Black



B 13
Black