## Position of Parts in Instrument Panel <LHD Before Aug. 2009 Production>




* 5:M/T
* 6:w/ LEXUS Navigation System
* 8:w/o Rear Sunshade
* 12:From Aug. 2008 Production
* 14:*6 *12
* 15:Refer to the Service Bulletin
  for the installation position of the parts.

J 61 Radio Receiver Assembly
J 62 Radio Receiver Assembly
J 63 Radio Receiver Assembly
J 65 Radio Receiver Assembly
J 66 Radio Receiver Assembly
J 67 Antenna Amplifier
J 68 Heated Oxygen Sensor (Bank 1 Sensor 2)
J 69 ID Code Box
J 70 Junction Connector
J 71 Junction Connector
J 73 Register Illumination (RH)
J 74 Body ECU (Cowl Side J/B RH)
J 75 Body ECU (Cowl Side J/B RH)
J 76 Gateway ECU
J 77 Skid Control ECU
J 78 Skid Control ECU
J 79 Airbag Squib (Front Passenger's Side Knee Airbag)
J 80 Junction Connector
J 81 Junction Connector
J 82 Junction Connector
J 84 Junction Connector
J 87 ETCS Snow SW
J 88 Parking Brake SW
J 89 Headlamp Leveling SW
J 90 Front Wiper Deicer SW
J 91 Airbag Cut Off SW
J 92 Television Camera Controller
J 93 Television Camera Controller
J 94 Junction Connector
J 95 Power Heater SW
J 99 Stop Lamp Control Relay
J 100 Register Illumination (Center)
J 101 Yaw Rate Sensor
J 102 Clock Assembly

J 61
Blue




J 62
White




J 63
White




J 65
White

J 66
White




J 67
White

J 68
Dark Gray

J 69
White




J 70
White




J 71
White




J 73
White




J 74
White




J 75
White




J 76
White




J 77
Gray




J 78
Gray



J 79
Black




J 80
Blue




J 81
White




J 82
White




J 84
White




J 87
Blue




J 88
Brown

(LHD)

J 88
Black

(RHD)

J 89
Green

J 90
Black




J 91
Black

J 92
Black




J 93
Black




J 94
White




J 95
Black




J 99
Black




J100
White

J101
Black




J102
White