(Cont. next page)

Power Seat (Driver' s Seat) (RHD)




Power Seat (Driver' s Seat) (RHD)
* 1 : 10 Way Power Seat Type
5
6
7
8
v4
Front Power Seat Switch RH
Release
Lumbar
Hold
Up
Head Rest
Down
Up
Lifter
Down
Up
Front Vertical
Down
Front
Reclining
Rear
Front
Slide
Rear
R
H
HUP
HDWN
LUP
LDWN
FUP
FDWN
RCLF
RCLR
SLDF
SLDR
W–B
E
x5
Front Seat Headrest Assembly RH
xv1
LFLR
LFLF
HEDU
HEDD
LFTU
LFTD
FRVU
FRVD
RCLF
RCLR
SLDF
SLDR
H–
SSRH
H+
v10(A), v11(B), v12(C)
Position Control ECU Assembly RH
SSRS
SLD+
SLD–
DRDC
DBCL
SENG
GND
Electric Tension Reducer System <28–2>
v1
Power Seat Slide Motor RH
(Front Seat Adjuster Assembly RH)
v13
No. 10 Junction Connector
BR(*1)
Xv2
XB
A
B
C
D
E