
(IG)
10A
LUG–IG1
NO. 1
(BAT)
5A
LUG–B
NO. 2
(BAT)
30A
EPB
NO. 1
X66(A), X67(B)
Parking Brake ECU Assembly
+B
BECU
IG
CA2H
CA2L
8 A
2 B
4 B
9 B
1 B
2
6
5
L
L
G
B
GR
B
V
P
2 bX2
22 bX1
LA–B
42 bX1
B
P
V


X66(A), X67(B)
Parking Brake ECU Assembly
LCK1
LCK2
REL1
REL2
12 B
15 B
16 B
13 B
W
BE
LG
SB
26 PX1
27 PX1
28 PX1
48 PX1
B
R
G
SB
W–B
1
2
8
9
14
LOK1
LOK2
RLS1
RLS2
GND1
LOK1
LOK2
RLS1
RLS2
Lock
Free
Full Travel
Release
Free
Full Travel
P36
Electric Parking Brake Switch Assembly
P
V
P
V
PD


X66(A), X67(B)
Parking Brake ECU Assembly
TSEN
TSN2
VT
TGND
SG
M+
M–
GND1
TX
8 B
6 B
7 B
14 B
10 B
2 A
1 A
3 A
7 A
(Shielded)
R
W
B
G
G
L
W–B
R
2 XX2
1 XX2
23 PX1
G
L
P
5
10
6
1
2
8
7
TSEN
TSN2
VT
TGND
SG
M+
M–
IC1
IC2
M
X68
Parking Brake Actuator with Bracket Assembly
P
P
P
V
V
XI


(IG)
(BAT)
10A
IG2 D
NO. 1
10A
METER
2
2
12 3A
35 3A
G
V
P25(A)
Combination Meter Assembly
21 A
22 A
IG+
B
Speaker
5V IC
5V+B
Display Driver
I/F
Telltales
CPU
LED Driver
I/F
I/F
CAN I/F
EPB
CANH
CANL
ES
5 A
29 A
30 A
31 A
P
Y
W
W–B
W
Y
P
P
V
P
V
PC


P7(A)
Main Body ECU
CANL
CANH
4 A
5 A
W
BE
W
R
18
7
12
1
15
4
13
2
P107
No. 1 CAN
Junction Connector
W
Y
W
L
12 C
11 C
CANL
CANH
P58(C)
Air Conditioning
Amplifier Assembly
R
W
9 PX2
20 PX2
V
W
1 E
2 E
1 A
2 A
X88(A), X93(E)
No. 11 CAN
Junction Connector
R
W
8 PX2
19 PX2
W
B
10 PX4
5 PX4
W
V
2 E
1 E
2 D
1 D
X85(D), X86(E)
No. 10 CAN Junction Connector
W
R
9 PX4
4 PX4
W
P
W
B
W
Y
P
P
V
V


P46(C)
Radio Receiver Assembly
CANH
CANL
13 C
14 C
L
LG
10
21
P116
No. 4 CAN Junction Connector
8
19
B
LG
W
B
W
15
16
P59
Network Gateway ECU
6
21
CA5H
CA5L
CA3H
CA3L
CA6H
CA6L
CA2L
CA2H
CAYL
CAYH
CA1L
CA1H
14
5
7
22
20
19
8
23
G
W
W
Y
W
R
W
L
6 A
14 A (*1)
6 B
14 B (*2)
CANH
CANL
P12(A), P132(B)
DLC3
* 1 : Before Sep. 2018 Production
* 2 : From Sep. 2018 Production
L
W
R
W
Y
W
P
P
V
V


(BAT)
5A
STOP
2
13 3C
W
1
2
B
L
IC1
GND
3
A4
Stop Light Switch Assembly
W–B
AI
R
15 3C
23 3C
R
16 C
STP
10 B
CA2H
11 B
CA2L
CA1L
CA1H
9 B
8 B
A9(B), A10(C)
Skid Control ECU Assembly
LG
W
1 A
2 A
1 D
2 D
P125(A), P128(D)
No. 8 CAN Junction
Connector
Y
W
G
W
57 PA3
58 PA3
1 PX2
12 PX2
W
R
G
R
23 bX4
41 bX4
V
LG
LG
V
W
LG
L
W
R
W
Y
W
P
V
L
W
R
W
Y
W
P
V


b10
No. 18 CAN
Junction
Connector
X114
No. 17 CAN
Junction Connector
X96
No. 12 CAN
Junction Connector
bX4
PX3
PX4
LG
GR
R
G
V
W
L
P
Y


V
W
4 PX2
15 PX2
GR
P
W
BE
W
V
1 D
2 D
18
7
19
8
X100(A), X103(D), X104(E)
No. 13 CAN
Junction Connector
P108
No. 2 CAN
Junction Connector
2 A
1 A
1 E
2 E
15
4
P
V
G
P
W
G
7 AX5
18 AX5
2
3
CANL
CANH
W
LG
P35
Yaw Rate Sensor
W
LG
L
L
W
W
P
V


16 PX2
5 PX2
GR
V
37 bX4
19 bX4
W
G
G
W
12
1
3
14
b10
No. 18 CAN
Junction Connector
P124
No. 6 CAN
Junction Connector
2
13
14
3
2
13
12
1
B
W
W
GR
B
W
W
Y
20 bX4
38 bX4
13 PA1
12 PA1
B
GR
B
W
Y
W
13 A
26 A
CANH
CANL
CAND
CANU
A58(A)
ECM
25 A
12 A
6 PX2
17 PX2
L
W
W
B
B
W
GR
W
L
W


(IG)
10A
IG2 P
NO. 2
(ACC)
10A
ACC P
NO. 1
(BAT)
7. 5A
P CON
MAIN
2
29 4B
55 4A
1
LA–BE
15
16
P92
No. 7
Junction
Connector
GR
G
1 PA1
B
27 B
18 B
1 C
A53(A), P74(B), P75(C)
Shift Control ECU
IG2
ACC
BATT
CA1H
CA1L
CA2H
CA2L
E12
E01
E02
E03
E1
EC
9 B
8 B
6 B
5 B
17 C
6 C
5 C
4 C
1 B
11 B
Y
W
R
15 PA1
16 PA1
W–B
GR
PG


(BAT)
30A
P CON
MTR
P76
Transmission Floor Shift Assembly
VSX1
VSX2
VSX3
VSX4
VCX1
E2X1
VCX2
E2X2
VSI1
VSI2
VSI3
VSI4
VCX1
E2X1
VCX2
E2X2
A53(A), P74(B), P75(C)
Shift Control ECU
BUBI
BUBO
BMA2
BUB
BMA1
P CON
MTR
Relay
PX5
AX1
bX1
B
W
V
P
L
LG
GR
SB
Y
G
BE
LA–G


(IG)
10A
LUG–IG1
NO. 1
(BAT)
10A
LUG–B
NO. 5
P CON
MTR 2
Relay
25A
P CON
MTR 2
7. 5A
P CON
MAIN 2
5A
b5(A), b7(B)
Sub–Battery with
Control Assembly
IG
B
+BAT
BR
RO
G
L
R
P
B–W
W
B
GR


(BAT)
200A
R/B RR NO. 1
b9(B)
Fusible Link
Block Assembly
1 B
B–W
1 5B
BAT1
2ND BATT RELAY
RLY1
RD11
RD12
GND
1 5D
3 5D
6 5D
8 5D
V
L
SB
W–B
8 A
12 A
11 A
BUR
RD1
RD2
b5(A), b7(B)
Sub–Battery with
Control Assembly
CANH
CANL
3 A
10 A
GR
W
GR
W
bB

A4
Black



90980-12366

A9
Black



90980-12528

A10
Black



90980-12529

A53
White



90980-12560

A58
Black



90980-12931

P7
Black



90980-12C62

P12
White



90980-11665

P25
Black



90980-12557

P35
Black



90980-12303

P36
Black



90980-12370

P46
White



90980-12761

P58
White



90980-12760

P59
Black



90980-12912

P74
White



90980-12562

P75
White



90980-12561

P76
White



90980-12553

P92
White



90980-12B54

P107
White



90980-12B54

P108
White



90980-12B54

P116
Black



90980-12B54

P124
Black



90980-12B54

P125
White



90980-12827

P128
White



90980-12827

P132
White



90980-12D97

X66
White



90980-11362

X67
White



90980-12553

X68
White



90980-11596

X85
White



90980-12827

X86
White



90980-12827

X88
White



90980-12827

X93
White



90980-12827

X96
White



90980-12C68

X100
White



90980-12827

X103
White



90980-12827

X104
White



90980-12827

X114
White



90980-12372

b5
White



90980-12370

b7



b9



b10
Black



90980-12B54

3A
White



90980-12943

3C
White



90980-12A47

4A
White



90980-12943

4B
White



90980-12A48

5A



82675-28470

5B



90980-09877

5D
White



90980-12551

AX1
White



90980-12771



90980-12770

AX5
White



90980-12372



90980-12371

PA1
White



90980-12B22



90980-12B21

PA3
White



90980-12B22



90980-12B21

PX1
Gray



90980-12B20



90980-12B19

PX2
White



90980-12372



90980-12371

PX3
Gray



90980-12B20



90980-12B19

PX4
White



90980-12368



90980-12367

PX5
White



90980-12779



90980-12799



90980-11094

90980-11093



90980-12B20

90980-12B19



90980-11742

90980-11878



90980-12779

90980-12799