
(IG)
10A
LUG–IG1
NO. 4
2
6
R
20 bX1
LA–R
X12
Clearance Warning ECU Assembly
IG
EF
CBZ
E
S5
E5
12
10
11
27
19
20
R
W
LG
W–B
R
LG
20 PX3
42 PX3
1 AX2
12 AX2
W
LG
R
LG
2
Z–
Z+
1
P29
No. 1 Clearance Warning Buzzer
4 AD2
8 AD2
W
B
2
1
S
E
D2
Front Ultrasonic
Sensor Corner RH
XD


X12
Clearance Warning ECU Assembly
S7
E7
S8
E8
S6
E6
S2
E2
S4
E4
23
24
25
26
21
22
3
4
8
9
W
G
GR
P
V
B
BE
R
V
L
2 AX2
13 AX2
10 AX5
21 AX5
11 AX5
22 AX5
5 Xc1
12 Xc1
4 Xc1
11 Xc1
W
G
GR
P
V
B
BE
R
G
V
3 AD2
7 AD2
3 AD1
7 AD1
4 AD1
8 AD1
2
1
S
E
R
P
R
P
W
B
2
1
S
E
D3
Front Ultrasonic
Sensor Center RH
D4
Front Ultrasonic
Sensor Center LH
D1
Front Ultrasonic
Sensor Corner LH
c3
Rear Ultrasonic
Sensor Corner LH
c4
Rear Ultrasonic
Sensor Center LH


X12
Clearance Warning ECU Assembly
S3
E3
S1
E1
R2
R1
6
7
1
2
18
17
SB
LG
B
W
L
P
3
Xc1
9
Xc1
2
Xc1
8
Xc1
SB
LG
B
GR
2
1
2
1
S
E
S
E
c2
Rear Ultrasonic
Sensor Center RH
c1
Rear Ultrasonic
Sensor Corner RH
12
1
14
3
X109
No. 14 CAN
Junction Connector
BR
BR
B
BR
LG
10
A
4
A
11
A
+DP2
EAU
+DP
P19(A), z2(C)
Spiral Cable with Sensor Sub–Assembly
5
C
10
C
4
C
V
GR–V
Y
Left
Enter
Up
Down
Back
Right
Steering Pad Switch LH
z2(C)
Steering Pad Switch Assembly
L
W
W–B
W
L
PC


(BAT)
(IG)
10A
METER
10A
IG2 D
NO. 1
2
35 3A
12 3A
BR
B
LG
V
G
P25(A), P26(B)
Combination Meter Assembly
22 A
21 A
B
IG+
Display Driver
5V+B
5V IC
CPU
I/F
I/F
I/F
CAN I/F
I/F
MSSL
MSTI
MSM+
TX–
TX+
CANL
CANH
ES
1 A
3 A
2 A
9 B
10 B
30 A
29 A
31 A
BR
B
LG
W
R
W
Y
W–B
Y
W
W
L
L
R
W
W
L
PC


A9(B)
Skid Control ECU Assembly
SP1
CA1H
CA1L
22 B
8 B
9 B
P25(A), P26(B)
Combination Meter Assembly
LG
W
LG
55 PA3
7 AX5
18 AX5
3 PX4
8 PX4
LG
G
P
W
V
GR
P
1 E
2 E
19
8
4
10
X103(D), X104(E)
No. 13 CAN
Junction Connector
P108
No. 2 CAN
Junction Connector
X96
No. 12 CAN
Junction Connector
1 D
2 D
18
7
5
11
GR
P
W
BE
L
P
SI
20 A
4 PX2
15 PX2
2 PX4
7 PX4
LG
Y
W
W
Y
Y
Y
W
W
W
W
L
L
R
R
W
W


P59
Network Gateway ECU
CA2L
CA2H
CAXH
CAXL
CA3H
CA3L
CA1H
CA1L
CA5L
CA5H
P113(E), P114(F)
No. 3 CAN
Junction Connector
X110
No. 15 CAN
Junction Connector
PX2
W
B
Y
P
L
LG
BE
R


W
B
16 PX2
5 PX2
GR
V
37 bX4
19 bX4
G
W
12
1
b10
No. 18 CAN
Junction Connector
13
2
W
B
38 bX4
20 bX4
GR
B
17 PX2
6 PX2
W
L
3
14
P124
No. 6 CAN
Junction Connector
2
13
B
W
13 PA1
12 PA1
B
W
13 A
26 A
CANH
CANL
CAND
CANU
25 A
12 A
A58(A)
ECM
W
B
P76
Transmission Floor Shift Assembly
VSX1
VSX2
VSX3
VSX4
VCX1
E2X1
VCX2
E2X2
7
5
11
9
4
14
12
2
B
W
V
P
L
LG
GR
SB
19 C
21 C
23 C
25 C
20 C
24 C
22 C
26 C
VSI1
VSI2
VSI3
VSI4
VCX1
E2X1
VCX2
E2X2
CA2H
CA2L
6 B
5 B
P74(B), P75(C)
Shift Control ECU
R
W
15 PA1
16 PA1
Y
W
LG
B
R
W


∗ 3 : w/ Headup Display
P107
No. 1 CAN Junction Connector
X85(D), X86(E)
No. 10 CAN
Junction Connector
X88(A), X93(E)
No. 11 CAN
Junction Connector
P7(A)
Main Body ECU
CANH
CANL
PX4
PX2
(∗3)
W(∗3)
B(∗3)


P43(A), P46(C), P99(E)
Radio Receiver Assembly
CANL
CANH
CNL1
CNH1
14 C
13 C
6 C
5 C
LG
L
W
Y
21
10
15
4
P116
No. 4 CAN
Junction Connector
19
8
13
2
1
12
LG
B
W
(*3)
L
(*3)
R
W
15
14
TX–
TX+
MPX2
MPX1
P80
Meter Mirror
Sub–Assembly
13
12
W
(*3)
B
(*3)
W(*3)
B(*3)
LG
B
R
W



∗ 3 : w/ Headup Display

: There is no wire color information.

A9
Black



90980-12528

A58
Black



90980-12931

D1
Black



90980-11246

D2
Black



90980-11246

D3
Black



90980-11246

D4
Black



90980-11246

P7
Black



90980-12C62

P19
Black



90980-12370

P25
Black



90980-12557

P26
Black



90980-12767

P29
Black



90980-10825

P42
Black



90980-12554

P43
White



82824-52380

P46
White



90980-12761

P59
Black



90980-12912

P74
White



90980-12562

P75
White



90980-12561

P76
White



90980-12553

P80
White



90980-12763

P90
White



90980-12B54

P99
Blue

90980-12C80

P101
Blue

90980-12C80

P107
White



90980-12B54

P108
White



90980-12B54

P113
White



90980-12827

P114
White



90980-12827

P116
Black



90980-12B54

P124
Black



90980-12B54

X12
Black



90980-12924

X85
White



90980-12827

X86
White



90980-12827

X88
White



90980-12827

X93
White



90980-12827

X96
White



90980-12C68

X103
White



90980-12827

X104
White



90980-12827

X109
White



90980-12372

X110
White



90980-12372

b10
Black



90980-12B54

c1
Black



90980-11246

c2
Black



90980-11246

c3
Black



90980-11246

c4
Black



90980-11246

z2
Black



90980-12559

3A
White



90980-12943

4A
White



90980-12943

4B
White



90980-12A48

AD1
Black



90980-10897



90980-10896

AD2
Black



90980-10897



90980-10896

AX2
White



90980-12372



90980-12371

AX5
White



90980-12372



90980-12371

PA1
White



90980-12B22



90980-12B21

PA3
White



90980-12B22



90980-12B21

PX2
White



90980-12372



90980-12371

PX3
Gray



90980-12B20



90980-12B19

PX4
White



90980-12368



90980-12367

Xc1
Gray



90980-12326



90980-12716

bX1
Gray



90980-12B20



90980-12B19

bX4
White



90980-12779



90980-12799