Position of Parts in Engine Compartment <RHD Before Sep. 2012 Production>



A 1 Washer Motor
A 2 Washer Fluid Level Sensor
A 3 Headlight Cleaner Motor
A 4 Front Height Control Sensor LH
A 5 Front Speed Sensor LH
A 6 Headlight Cleaner Relay
A 7 Fog Light LH
A 8 Front Airbag Sensor LH
A 9 Fan Control ECU
A 12 Transmission Control ECU
A 13 Engine ECU
A 14 Engine ECU
A 15 Front Suspension Control Actuator LH
A 16 Fuel Pump Resistor
A 18 Brake Fluid Level Warning Switch
A 19 Skid Control ECU
A 20 Skid Control ECU
A 21 Skid Control ECU
A 22 Brake Stroke Simulator
A 23 Brake Accumulator Pump
A 24 Brake Accumulator Pump
A 25 Short Connector (Brake Stroke Simulator Cylinder)
A 26 Short Connector (Brake Stroke Simulator Cylinder)
A 27 Brake Actuator
A 28 Wireless Door Lock Buzzer
A 29 Security Horn
A 30 Front Wiper Deicer
A 31 Side Turn Signal Light LH
A 32 Wiper Motor

A 1
Black



A 2
Black



A 3
Black

A 4
Black



A 5
Gray



A 6
Gray



A 7
Brown

A 8
Yellow



A 9
Black



A 12
Gray



A 13
White



A 14
White



A 15
Black



A 16
Black



A 18
Black



A 19
Black



A 20
Black



A 21
Gray



A 22
Gray



A 23
Black



A 24
Black



A 25
Gray



A 26
Gray



A 27
Black



A 28
Black



A 29
Black

A 30
Gray



A 31
Gray



A 32
Black