
S14
S13
S24
S19
S20
S27
S25
S26
S35
S38
S36
S7
S6
S5
S2
S3
S4
S12
S11
S10
S18
S32
S29
S33
S34
S37

S 2 Front Tension Reducer LH
S 3 Front Pretensioner LH
S 4 Front Pre-Crash Seat Belt Motor LH
S 5 Side Airbag Sensor Assembly LH
S 6 Front Door Courtesy Light Switch Assembly LH
S 7 Height Adjustable Anchor Motor LH
S 10 Rear Electrical Key Oscillator
S 11 Main Fuel Sender Gauge Assembly
S 12 Rear Airbag Sensor LH
S 13 Radio Setting Condenser
S 14 Rear Door Courtesy Light Switch Assembly LH
S 18 Rear Header Speaker Assembly LH
S 19 Noise Filter (Rear Window Defogger)
S 20 Center Stop Light Assembly
S 24 Curtain Shield Airbag Assembly LH
S 25 Rear Window Shade Assembly
S 26 No.1 Luggage Compartment Light Assembly
S 27 Rear Pretensioner LH
S 29 Seat Vibration ECU
S 32 Parking Brake Actuator Assembly
S 33 Rear Light Assembly LH
S 34 No.1 Luggage Compartment Door Light Assembly
S 35 Television Camera Assembly
S 36 Luggage Door Closer Assembly
S 37 License Plate Light Assembly
S 38 Luggage Electrical Key Switch

S 2
White

S 3
Yellow



S 4
White



S 5
Yellow



S 6
White

S 7
Black



S 10
White



S 11
White

S 12
Yellow



S 13
Gray



S 14
White

S 18
White



S 19
White



S 20
White



S 24
Black



S 25
White



S 26
Gray



S 27
Yellow



S 29
White



S 32
White



S 33
White



S 34
Gray



S 35
White



S 36
White



S 37
White



S 38
White