
P7
P8
P4
P1
P12
P2
P3
Q3
Q2
Q1
Q4
P5
Q5
P10
P6
P11
P9
Q8
Q7
Q10
Q9
Q6

P 1 Height Adjustable Anchor Switch RH
P 2 Front Door Inside Handle Illumination Light Assembly RH
P 3 Security Indicator RH
P 4 Front Multiplex Network Door ECU RH
P 5 Front Door Courtesy Light RH
P 6 Height Adjustable Anchor Switch LH
P 7 Front Seat Memory Switch LH
P 8 Front Door Inside Handle Illumination Light Assembly LH
P 9 Security Indicator LH
P 10 Front Multiplex Network Door ECU LH
P 11 Front Door Courtesy Light Assembly LH
P 12 Front Seat Memory Switch RH

Q 1 Rear Door Inside Handle Illumination Light Assembly RH
Q 2 Rear Seat Memory Switch RH
Q 3 Rear No.3 Speaker Assembly RH
Q 4 Rear Room Temperature Sensor RH
Q 5 Rear Door Courtesy Light Assembly RH
Q 6 Rear Door Inside Handle Illumination Light Assembly LH
Q 7 Rear Seat Memory Switch LH
Q 8 Rear No.3 Speaker Assembly LH
Q 9 Rear Room Temperature Sensor LH
Q 10 Rear Door Courtesy Light Assembly LH

P 1
White



P 2
White



P 3
White



P 4
White



P 5
White

P 6
White



P 7
White



P 8
White



P 9
White



P 10
White



P 11
White



P 12
White



Q 1
White



Q 2
Black



Q 3
White



Q 4
White



Q 5
White

Q 6
White



Q 7
Black



Q 8
White



Q 9
White



Q 10
White