Position of Parts in Instrument Panel <LHD Before Nov. 2009 Production>



L 1 Turn Signal Flasher Assembly
L 2 Skid Control Buzzer Assembly
L 3 Luggage Door Opening Switch Assembly
L 4 Coin Box Illumination Light
L 5 Driver Side Front Register Illumination
L 6 Outer Mirror Switch Assembly
L 7 Driver Side Knee Airbag (Lower No.1 Instrument Panel Airbag Assembly)
L 8 Light Control Rheostat
L 9 Front No.2 Speaker Assembly LH
L 10 Combination Meter
L 11 Main Body ECU
L 12 Main Body ECU
L 13 Main Body ECU
L 14 Front Duct Sensor LH
L 15 Certification ECU Assembly
L 16 Certification ECU Assembly
L 17 Front Acceleration Sensor Assembly
L 18 Driver Monitor ECU Assembly
L 19 Clearance Warning ECU Assembly
L 20 Driver Monitor Camera
L 21 Steering Sensor
L 22 Spiral Cable Sub-Assembly
L 23 Spiral Cable Sub-Assembly
L 24 Spiral Cable Sub-Assembly
L 25 Windshield Wiper Switch Assembly
L 26 Power Tilt Motor
L 27 Pre-Crash System Cancel Switch Assembly

L 1
Gray



L 2
Blue



L 3
Black



L 4
Gray



L 5
White



L 6
White



L 7
Black



L 8
White



L 9
White



L 10
White



L 11
White



L 12
White



L 13
White



L 14
Black



L 15
White



L 16
White



L 17
Black



L 18
White



L 19
White



L 20
White



L 21
White



L 22
Yellow



L 23
Black



L 24
Black



L 25
White



L 26
White



L 27
Gray