POWER SEAT (FRONT PASSENGER'S SEAT) [LHD]




W–B
B 7
W–B
B–R
W–B
1
2
B
E
P24
POWER SEAT CONTROL SW
(FRONT PASSENGER' S SEAT
LUMBAR SUPPORT)
R
H
3
4
B
R–L
1
M
2
P37
POWER SEAT MOTOR
(FRONT PASSENGER' S SEAT
LUMBAR SUPPORT CONTROL)
W–B
7
BG2
W–B
IR