054G5–03

LOCATION



P *1: w/ LEXUS Navigation System
*2: w/o LEXUS Navigation System
*3: For RHD vehicles, components and parts are located on the opposite side of the vehicle.

B74432